

YOUR STEP-BY-STEP GUIDE TO GETTING THE MOST FROM TRIMBLE TECHNOLOGY.

MARCH 2025

TRIMBLE EARTHWORKS FAQ: TD540 – Select Screen Orientation

Welcome to **SITECH SmartGuide & Go** – your go-to resource for quick, clear, and stepby-step guidance on using Trimble technology with confidence. This series is designed to help you navigate common setup tasks, optimise performance, and get the most out of your equipment—without needing to call support.

In this guide, we'll walk you through **Selecting Screen Orientation on your TD540**, with easy-to-follow instructions to ensure you're up and running in no time.

1. Drag your finger from the very top of the screen to reveal the **android** screen menu.



2. A page will pull down over the home screen. Select Settings


	1:33	$ \land \land \land \land \land \land \land \land \land$
	Fri, 14 Feb 🚸 ↔	
$\square \rangle$	中 し 日 ① 〇 〇	File Filipper SNMQ4x
	Notifications	
	🖁 Machine Control Plugin	$\langle \chi \chi \chi \rangle$
	Trimble® Earthworks Connected	
	connected	
	Android System	
	Configure physical keyboard Tap to select language and layout	
	MC Installer • 2h	IOLOGY PROVIDER
	MC Installer All apps are up to date	
	r 译 Remote.It ScreenView • 2h	7556
	connections service	/ 550
	E License Daemon Service • 2h	
	License Daemon Service	lo.
	- J Jannas Naaman Camilas Gastina 🌡 🕼 🗊 🗊 🖓	IC. *
	• •	•

3. Select **Display**

	1:34 👸	a 🗅 Å •	* ↔
		rergency information responders see your information	
		ht Light schedule tically tint screen every night	×
\uparrow	?	Network and internet Wi-Fi, data usage and hotspot	
	60	Connected devices Bluetooth, NFC	
		Apps and notifications Recent apps, default apps	
	0	Display Wallpaper, sleep, font size	
	2	Touch Sensitivity	
	⊲€	Sound Volume, vibration, Do Not Disturb	
		Storage 29% used - 22.84 GB free	
	@	Privacy Permissions, account activity, personal data	



4. Select Screen Orientation



5. Now you can select the orientation required. Landscape or Portrait

1:34 🥉	■ <u>0</u> iš •						*↔
÷	Display						Q
	Dark theme On/Will never turn off automatically						
	Night Light Off/Will never turn on automatically	Scr	een orientation				
	Adaptive brightness Off		Landscape				
		0	Portrait				
	Wallpaper	0	Landscape flipped				
		0	Portrait flipped				
	Font size				CANCEL		
	Default						
~							
			•	•			



6. Select home to exit.

1:34 🥉	▲ 🖸 🔒 •		*↔
÷	Display		Q
	Dark theme On/Will never turn off automatically		
		Screen orientation	
		Landscape	
		O Portrait	
		O Landscape flipped	
		O Portrait flipped	
		CANCEL	
~			
		< ● ■	
		^	
		17	

